

# Installation Instruction



**Fig. 1 — Sizes 06K to 33K**

**NOTES:** Read the entire instruction manual before starting the installation.  
Images are for illustration purposes only. Actual models may differ slightly.

## TABLE OF CONTENTS

|                                                 | PAGE |
|-------------------------------------------------|------|
| SAFETY CONSIDERATIONS.....                      | 2    |
| CAPACITY .....                                  | 7    |
| ACCESSORIES.....                                | 8    |
| DIMENSIONS.....                                 | 9    |
| CLEARANCES .....                                | 13   |
| INSTALLATION .....                              | 14   |
| REFRIGERANT PIPING.....                         | 16   |
| EVACUATE COIL AND TUBING SYSTEM.....            | 18   |
| WIRING .....                                    | 19   |
| ELECTRICAL DATA.....                            | 19   |
| INSTALL THE OUTDOOR UNIT.....                   | 20   |
| Step 1 - Select the Installation Location.....  | 20   |
| Step 2 - Install the Drain Joint.....           | 21   |
| Step 3 - Anchor the Outdoor Unit.....           | 22   |
| Step 4 - Connect Signal and Power Cables .....  | 23   |
| START-UP .....                                  | 25   |
| CARE AND MAINTENANCE.....                       | 25   |
| TROUBLESHOOTING .....                           | 25   |
| ERROR CODES.....                                | 26   |
| DUCTLESS START-UP CHECKLIST - Single Zone ..... | 27   |

## SAFETY CONSIDERATIONS

Installing, starting up, and servicing air- conditioning equipment can be hazardous due to system pressures, electrical components, and equipment location (roofs, elevated structures, etc.).

Only trained, qualified installers and service mechanics should install, start- up, and service this equipment.

Untrained personnel can perform basic maintenance functions such as coil cleaning. All other operations should be performed by trained service personnel only.

When working on the equipment, observe the precautions in the literature and on tags, stickers, and labels attached to the equipment.

Follow all safety codes. Wear safety glasses and work gloves. Keep a quenching cloth and a fire extinguisher nearby when brazing. Use care in handling, rigging, and setting bulky equipment.

Read these instructions thoroughly and follow all warnings or cautions included in the literature and attached to the unit. Consult local building codes and National Electrical Code (NEC) for special requirements. Recognize safety information.

### This is the safety - alert symbol

When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury. Understand these signal words: **DANGER**, **WARNING**, and **CAUTION**. These words are used with the safety- alert symbol.

**DANGER** identifies the most serious hazards which results in severe personal injury or death.

**WARNING** signifies hazards which could result in personal injury or death.

**CAUTION** is used to identify unsafe practices which may result in minor personal injury or product and property damage.

**NOTE** is used to highlight suggestions which results in enhanced installation, reliability, or operation.

The following symbols may be seen on the unit.

**Table 1 — Symbols displayed on the indoor unit or outdoor unit**

|                                                                                    |                |                                                                                                                                                                       |
|------------------------------------------------------------------------------------|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <b>WARNING</b> | This symbol shows that this appliance used a flammable refrigerant. If the refrigerant is leaked and exposed to an external ignition source, there is a risk of fire. |
|  | <b>CAUTION</b> | This symbol shows that the operation manual should be read carefully.                                                                                                 |
|  | <b>CAUTION</b> | This symbol shows that a service personnel should be handling this equipment with reference to the installation manual.                                               |
|  | <b>CAUTION</b> |                                                                                                                                                                       |
|  | <b>CAUTION</b> | This symbol shows that information is available such as the operating manual or installation manual.                                                                  |

**R-454B**


Refrigerant  
Safety Group  
A2L

**R-454B**

**WARNING – Risk of Fire due to Flammable Refrigerant Used. Follow Handling Instructions Carefully in Compliance with National Regulations**

**NOTE: Risk of Fire. Flammable refrigerant used. To be repaired only by trained service personnel. Do not puncture refrigerant tubing.**


WARNING

**PERSONAL INJURY AND PROPERTY DAMAGE HAZARD**

For continued performance, reliability, and safety, the only approved accessories and replacement parts are those specified by the equipment manufacturer. The use of non-manufacturer approved parts and accessories could invalidate the equipment limited warranty and result in a fire risk, equipment malfunction, and failure.

Please review the manufacturer's instructions and replacement parts catalogs available from your equipment supplier.


WARNING

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.



## WARNING

### ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

Before installing, modifying, or servicing system, the main electrical disconnect switch must be in the **OFF** position. There may be more than 1 disconnect switch. Lock out and tag switch with a suitable warning label.



## WARNING



### EXPLOSION HAZARD

Failure to follow this warning could result in death, serious personal injury, and/or property damage.

Never use air or gases containing oxygen for leak testing or operating refrigerant compressors. Pressurized mixtures of air or gases containing oxygen can lead to an explosion.



## WARNING

### FOR FLAMMABLE REFRIGERANTS

Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.

The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).

Do not pierce or burn.

Be aware that refrigerants may not contain an odor.



## CAUTION

### EQUIPMENT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage or improper operation.

Do not bury more than 36 in. (914 mm) of refrigerant pipe in the ground. If any section of pipe is buried, there must be a 6 in. (152 mm) vertical rise to the valve connections on the outdoor units. If more than the recommended length is buried, refrigerant may migrate to the cooler buried section during extended periods of system shutdown. This causes refrigerant slugging and could possibly damage the compressor at start-up.

## 1. Installation (where refrigerant pipes are allowed)

- Any person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance with an industry recognized assessment specification.
- Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- That the installation of pipe-work shall be kept to a minimum.
- That pipe-work shall be protected from physical damage.
- Where refrigerant pipes shall be compliance with national gas regulations.
- That mechanical connections shall be accessible for maintenance purposes.
- Be more careful that foreign matter (oil, water, etc) does not enter the piping. Also, when storing the piping, securely seal the opening by pinching, taping, etc.
- Appliance shall be stored in a well ventilated area where the room size corresponds to the room area as specific for operation.
- Joints shall be tested with detection equipment with a capability of 1/8 oz (5g)/year of refrigerant or better, with the equipment in standstill and under operation or under a pressure of at least these standstill or operation conditions after installation.
- In cases that require mechanical ventilation, ventilation openings shall be kept clear of obstruction.

**LEAK DETECTION SYSTEM** installed. Unit must be powered except for service. For the unit with refrigerant sensor, when the refrigerant sensor detects refrigerant leakage, the indoor unit will display a error code and emit a buzzing sound, the compressor of outdoor unit will immediately stop, and the indoor fan will start running. The service life of the refrigerant sensor is 15 years. When the refrigerant sensor malfunctions, the indoor unit will display the error code FHCC. The refrigerant sensor can not be repaired and can only be replaced by the manufacture. It shall only be replaced with the sensor specified by the manufacture.

## 2. Because a FLAMMABLE REFRIGERANT is used

The requirements for installation space of appliance and/or ventilation requirements are determined according to:

- the mass charge amount (M) used in the appliance,
- the installation location,
- the type of ventilation of the location or of the appliance.
- piping material, pipe routing, and installation shall include protection from physical damage in operation and service, and be in compliance with national and local codes and standards, such as ASHRAE 15, IAPMO Uniform Mechanical Code, ICC International Mechanical Code, or CSA B52. All field joints shall be accessible for inspection prior to being covered or enclosed.
- that protection devices, piping, and fittings shall be protected as far as possible against adverse environmental effects, for example, the danger of water collecting and freezing in relief pipes or the accumulation of dirt and debris;
- that piping in refrigeration systems shall be so designed and installed to minimize the likelihood of hydraulic shock damaging the system;
- that steel pipes and components shall be protected against corrosion with a rustproof coating before applying any insulation;
- that precautions shall be taken to avoid excessive vibration or pulsation;
- the minimum floor area of the room shall be mentioned in the form of a table or a single figure without reference to a formula;
- after completion of field piping for split systems, the field pipework shall be pressure tested with an inert gas and then vacuum tested prior to refrigerant charging, according to the following requirements:

- a. The minimum test pressure for the low side of the system shall be the low side design pressure and the minimum test pressure for the high side of the system shall be the high side design pressure, unless the high side of the system cannot be isolated from the low side of the system in which case the entire system shall be pressure tested to the low side design pressure.
  - b. The test pressure after removal of pressure source shall be maintained for at least 1 hour with no decrease of pressure indicated by the test gauge, with test gauge resolution not exceeding 5% of the test pressure.
  - c. During the evacuation test, after achieving a vacuum level specified in the manual or less, the refrigeration system shall be isolated from the vacuum pump and the pressure shall not rise above 1500 microns within 10 minutes. The vacuum pressure level shall be specified in the manual, and shall be the lesser of 500 microns or the value required for compliance with national and local codes and standards, which may vary between residential, commercial, and industrial buildings.
- field-made refrigerant joints indoors shall be tightness tested according to the following requirements: The test method shall have a sensitivity of 1/8 oz (5g)/year of refrigerant or better under a pressure of at least 125% of the maximum allowable pressure. No leak shall be detected.

### 3. Qualification of workers

Any maintenance, service and repair operations must be required qualification of the working personnel. Every working procedure that effects safety means shall only be carried out by competent persons that joined the training and achieved competence should be documented by a certificate. The training of these procedures is carried out by national training organizations or manufacturers that are accredited to teach the relevant national competency standards that may be set in legislation. Examples for such working procedures are:

- breaking into the refrigerating circuit;
- opening of sealed components;
- opening of ventilated enclosures.

## Information Servicing

1. Checks to the area  
Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimized. For repair to the refrigerating system, the following precautions shall be complied with prior to conducting work on the system.
2. Work procedure  
Works shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapor being present while the work is being performed.
3. General work area  
All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. work in confined spaces shall be avoided.
4. Checking for presence of refrigerant  
The area shall be checked with an appropriate refrigerant detector prior to and during work to ensure the technician is aware of potentially flammable atmospheres. Ensure that the leak detection equipment is suitable for use with flammable refrigerants (no sparking, adequately sealed, or intrinsically safe).
5. Presence of fire extinguisher  
If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry power or CO2 fire extinguisher adjacent to the charging area.
6. No ignition sources  
No person carrying out work in relation to a REFRIGERATING SYSTEM which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. “No Smoking” signs shall be displayed.
7. Ventilated area  
Ensure that the area is in the open or that it adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.
8. Checks to the refrigeration equipment  
Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer’s maintenance and service guidelines shall be followed. If in doubt consult the manufacturer’s technical department for assistance. The following checks shall be applied to installations using FLAMMABLE REFRIGERANTS:
  - The actual refrigerant charge is in accordance with the room size within which the refrigerant containing parts are installed;
  - The ventilation machinery and outlets are operating adequately and are not obstructed;
  - If an indirect refrigerating circuit is being used, the secondary circuits shall be checked for the presence of refrigerant;
  - Marking to the equipment continues to be visible and legible, marking and signs that are illegible shall be corrected;
  - Refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.
9. Checks to electrical devices  
Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, and adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised. Initial safety checks shall include:
  - That capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking
  - That there no live electrical components and wiring are exposed while charging, recovering or purging the system
  - That there is continuity of earth bonding
10. Sealed electrical components shall be replaced.
11. Intrinsically safe components must be replaced.
12. Cabling  
Check that cabling is not subjected to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

### 13. Detection of flammable refrigerants

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

The following leak detection methods are deemed acceptable for refrigerant systems. Electronic leak detectors that have a sensitivity of 1/8 oz (5g) may be used to detect refrigerant leaks but, in the case of FLAMMABLE REFRIGERANTS, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25% maximum) is confirmed. Leak detection fluids are also suitable for use in external leak detection.

**NOTE: Examples of leak detection fluids are as follows:**

- **Bubble method**
- **Fluorescent method agents**

If a leak is suspected, all naked flames shall be removed/extinguished.

If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak. See the following instructions of removal of refrigerant.

### 14. Removal and evacuation

When breaking into the refrigerant circuit to make repairs - or for any other purpose conventional procedures shall be used. However, for flammable refrigerants it is important that best practice be followed, since flammability is a consideration.

The following procedure shall be adhered to:

- a. safely remove refrigerant following local and national regulations;
- b. evacuate;
- c. purge the circuit with nitrogen;
- d. evacuate;
- e. continuously flush or purge with nitrogen when using flame to open circuit; and open the circuit.

The refrigerant charge shall be recovered into the correct recovery cylinders. Charging must be performed by liquid charging method. For appliances containing flammable refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerants. This process might need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems.

For appliances containing flammable refrigerants, refrigerants purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum (optional for A2L). This process shall be repeated until no refrigerant is within the system (optional for A2L). When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.

The outlet for the vacuum pump shall not be close to any potential ignition sources, and ventilation shall be available.

### 15. Charging procedures

In addition to conventional charging procedures, the following requirements shall be followed:

- Works shall be undertaken with appropriate tools only. If uncertain, consult the manufacturer of the tools for use with flammable refrigerants.

- Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
- Cylinders shall be kept upright.
- Charging must be performed by liquid charging method.
- Ensure that the refrigeration system is grounded prior to charging the system with refrigerant.
- Label the system when charging is complete.
- Extreme care shall be taken to avoid overfilling the refrigeration system.
- Prior to recharging the system, it shall be pressure tested with oxygen free nitrogen (OFN). The system shall be leak tested on completion of charging but before commissioning. A follow up leak test shall be carried out prior to leaving the site.

### 16. Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task is commenced.

- a. Become familiar with the equipment and its operation
- b. Isolate system electrically
- c. Before attempting the procedure, ensure the following:
  - Mechanical handling equipment is available, if required, for handling refrigerant cylinders
  - All personal protective equipment is available and being used correctly
  - The recovery process is supervised at all times by a competent person
  - Recovery equipment and cylinders conform to the appropriate standards
- d. Pump down refrigerant system, if possible.
- e. If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f. Make sure that cylinder is situated on the scales before recovery takes place.
- g. Start the recovery machine and operate in accordance with instructions.
- h. Do not overfill cylinders (no more than 80% volume liquid charge).
- i. Never exceed the maximum working pressure of the cylinder.
- j. When the cylinders have been filled correctly and the process complete, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k. Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

### 17. Labeling

Equipment shall be labeled stating that it has been decommissioned and emptied of refrigerant. The label shall be dated and signed. For appliances containing FLAMMABLE REFRIGERANTS, ensure that there are labels on the equipment stating the equipment contains FLAMMABLE REFRIGERANT.

## 18. Recovery

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge is available. All cylinders to be used are designated for the recovered refrigerant and labeled for that refrigerant (i. e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of the flammable refrigerant. If in doubt, the manufacturer should be consulted. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition.

The recovered refrigerant shall be processed according to local legislation in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.

If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The compressor body shall not be heated by an open flame or other ignition sources to accelerate this process. When oil is drained from a system, it shall be carried out safely.

## 19. Transportation, marking, and storage for units

a. Transport of equipment containing flammable refrigerants.

Compliance with the transport regulations.

b. Marking of equipment using signs.

Compliance with local regulations.

c. Disposal of equipment using flammable refrigerants.

Compliance with national regulations.

d. Storage of equipment/appliances

The storage of equipment should be in accordance with the manufacturer's instructions.

e. Storage of packed (unsold) equipment

Storage package protection should be constructed such that mechanical damage to the equipment inside the package will not cause a leak of the refrigerant charge. The maximum number of pieces of equipment permitted to be stored together will be determined by local regulations..

Table 2 — A (min)

| hinst: Height Above Floor Level to Center of Indoor Unit / feet (meters) |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |             |             |             |             |             |             |
|--------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|-------------|-------------|-------------|-------------|-------------|
| MC or Mrel<br>Refrigerant Charge Amount<br>pounds (kilograms)            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | ≤ 7.2 (2.2) | 7.5 (2.3)   | 7.9 (2.4)   | 8.5 (2.6)   | 9.2 (2.8)   | 9.8 (3.0)   |
|                                                                          | ≤ 3.91 (1.776)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 12 (1.10)   |             |             |             |             |             |
|                                                                          | 4.0 (1.8)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 60 (5.53)   | 57 (5.29)   | 55 (5.07)   | 50 (4.68)   | 47 (4.34)   | 44 (4.05)   |
|                                                                          | 4.4 (2.0)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 66 (6.14)   | 63 (5.88)   | 61 (5.63)   | 56 (5.2)    | 52 (4.83)   | 48 (4.5)    |
|                                                                          | 4.9 (2.2)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 73 (6.76)   | 70 (6.46)   | 67 (6.19)   | 62 (5.72)   | 57 (5.31)   | 53 (4.95)   |
|                                                                          | 5.3 (2.4)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 79 (7.37)   | 76 (7.05)   | 73 (6.76)   | 67 (6.24)   | 62 (5.79)   | 58 (5.41)   |
|                                                                          | 5.7 (2.6)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 86 (7.99)   | 82 (7.64)   | 79 (7.32)   | 73 (6.76)   | 68 (6.27)   | 63 (5.86)   |
|                                                                          | 6.2 (2.8)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 93 (8.6)    | 89 (8.23)   | 85 (7.88)   | 78 (7.28)   | 73 (6.76)   | 68 (6.31)   |
|                                                                          | 6.6 (3.0)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 99 (9.21)   | 95 (8.81)   | 91 (8.45)   | 84 (7.8)    | 78 (7.24)   | 73 (6.76)   |
|                                                                          | 7.1 (3.2)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 106 (9.83)  | 101 (9.4)   | 97 (9.01)   | 90 (8.32)   | 83 (7.72)   | 78 (7.21)   |
|                                                                          | 7.5 (3.4)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 112 (10.44) | 108 (9.99)  | 103 (9.57)  | 95 (8.84)   | 88 (8.2)    | 82 (7.66)   |
|                                                                          | 7.9 (3.6)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 119 (11.06) | 114 (10.58) | 109 (10.14) | 101 (9.36)  | 94 (8.69)   | 87 (8.11)   |
|                                                                          | 8.4 (3.8)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 126 (11.67) | 120 (11.16) | 115 (10.7)  | 106 (9.88)  | 99 (9.17)   | 92 (8.56)   |
|                                                                          | 8.8 (4.0)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 132 (12.29) | 126 (11.75) | 121 (11.26) | 112 (10.4)  | 104 (9.65)  | 97 (9.01)   |
|                                                                          | 9.3 (4.2)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 139 (12.9)  | 133 (12.34) | 127 (11.82) | 117 (10.91) | 109 (10.14) | 102 (9.46)  |
|                                                                          | 9.7 (4.4)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 145 (13.51) | 139 (12.93) | 133 (12.39) | 123 (11.43) | 114 (10.62) | 107 (9.91)  |
|                                                                          | 10.1 (4.6)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | 152 (14.13) | 145 (13.51) | 139 (12.95) | 129 (11.95) | 119 (11.1)  | 112 (10.36) |
|                                                                          | 10.6 (4.8)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | 159 (14.74) | 152 (14.1)  | 145 (13.51) | 134 (12.47) | 125 (11.58) | 116 (10.81) |
|                                                                          | 11.0 (5.0)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | 165 (15.36) | 158 (14.69) | 152 (14.08) | 140 (12.99) | 130 (12.07) | 121 (11.26) |
| A-min: Required Minimum Room Area / Square Feet (Square Meters)          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |             |             |             |             |             |             |
| AREA<br>FORMULA                                                          | <b>A<sub>min</sub></b> is the required minimum room area in ft <sup>2</sup> /m <sup>2</sup><br><b>mc</b> is the actual refrigerant charge in the system in ft/kg<br><b>mREL</b> is the refrigerant releasable charge in ft/kg<br><b>hinst</b> is the height of the center of the appliance relative to the floor of the room after installation.<br><b>WARNING:</b> The minimum room area or minimum room area of conditioned space is based on releasable charge or total system refrigerant charge. |             |             |             |             |             |             |

**For R454B refrigerant charge amount and minimum room area:**

The indoor unit should be installed at least 5.9ft/1.8m above the floor, and the minimum room area for operation or storage should be as specified in Table 1.

**CAPACITY**

Table 3 — Capacity


| CAPACITY | OUTDOOR      |
|----------|--------------|
| 6k       | 37MAHAQ06AA3 |
| 9k       | 37MAHAQ09AA3 |
| 12k      | 37MAHAQ12AA3 |
| 18k      | 37MAHAQ18AA3 |
| 24k      | 37MAHAQ24AA3 |
| 33k      | 37MAHAQ33AA3 |

## ACCESSORIES

The system is shipped with the following accessories. Use all of the installation parts and accessories to install the system. Improper installation may result in water leakage, electrical shock and fire, or cause the equipment to fail. Keep the installation manual in a safe place and do not discard any other accessories until the installation work has been completed.

**Table 4 — Accessories**

| PART NO. | PART NAME                                                                                  | QTY. |
|----------|--------------------------------------------------------------------------------------------|------|
| 1        | Outdoor unit                                                                               | 1    |
| -        | Literature package including installation instructions and warranty                        | 1    |
| -        | Mounting pads for the outdoor unit (helps with vibration prevention during unit operation) | 4    |
| -        | Drain Joint                                                                                | 1    |
| -        | Drain Hose                                                                                 | 1    |



**Fig. 2 — Outdoor Unit**

**NOTE:**

- If the outdoor unit is higher than the indoor unit, prevent rain from flowing into the indoor unit along the connection pipe by making a downward arc in the connection pipe before it enters the wall to the indoor unit. This ensures that rain drips from the connection pipe before it enters the wall.
- Piping and the interconnecting wiring are field supplied.
- Figure 2 is only a sketch. The actual model may differ slightly.

Table 5 lists the units covered in this document.

**Table 5 — Unit Sizes**


| SYSTEM TONS | BTUH   | VOLTAGE   | MODEL        |
|-------------|--------|-----------|--------------|
| 0.5         | 6,000  | 208/230-1 | 37MAHAQ06AA3 |
| 0.75        | 9,000  | 208/230-1 | 37MAHAQ09AA3 |
| 1           | 12,000 | 208/230-1 | 37MAHAQ12AA3 |
| 1.5         | 18,000 | 208/230-1 | 37MAHAQ18AA3 |
| 2           | 24,000 | 208/230-1 | 37MAHAQ24AA3 |
| 3           | 33,000 | 208/230-1 | 37MAHAQ33AA3 |




## DIMENSIONS

**Table 6 — Dimensions and Weights**

| SYSTEM SIZE        |           | 06K                                    | 09K                                    | 12K                                    | 18K                                    | 24K                                     | 33K                                     |
|--------------------|-----------|----------------------------------------|----------------------------------------|----------------------------------------|----------------------------------------|-----------------------------------------|-----------------------------------------|
|                    |           | (208/230 V)                            | (208/230 V)                            | (208/230V)                             | (208/230 V)                            | (208/230 V)                             | (208/230 V)                             |
| Height (H)         | in (mm)   | 21.85 (555)                            | 21.81 (554)                            | 21.81 (554)                            | 26.50 (673)                            | 31.89 (810)                             | 31.89 (810)                             |
| Width (W)          | in (mm)   | 30.12 (765)                            | 31.69 (805)                            | 31.69 (805)                            | 35.04 (890)                            | 37.24 (946)                             | 37.24(946)                              |
| Depth (D)          | in (mm)   | 11.93 (303)                            | 12.99 (330)                            | 12.99 (330)                            | 13.46 (342)                            | 16.14 (410)                             | 16.14 (410)                             |
| Weight - Net       | lbs. (kg) | 62.17 (28.2)                           | 72.75 (33.0)                           | 72.75 (33.0)                           | 99.87 (45.3)                           | 130.29 (59.1)                           | 130.29 (59.1)                           |
| <b>PACKAGING</b>   |           |                                        |                                        |                                        |                                        |                                         |                                         |
| Height (H)         | in (mm)   | 24.02 (610)                            | 24.21(615)                             | 24.21(615)                             | 29.13 (740)                            | 34.84 (885)                             | 34.84(885)                              |
| Width (W)          | in (mm)   | 34.92 (887)                            | 36.02 (915)                            | 36.02 (915)                            | 39.17 (995)                            | 42.91(1090)                             | 42.91(1090)                             |
| Depth (D)          | in (mm)   | 13.27(337)                             | 14.57(370)                             | 14.57 (370)                            | 15.67(398)                             | 19.69 (500)                             | 19.69(500)                              |
| Weight - Gross     | lbs. (kg) | 67.68 (30.7)                           | 78.70 (35.7)                           | 78.70 (35.7)                           | 107.80 (48.9)                          | 141.31(64.1)                            | 141.31 (64.1)                           |
| Carton Drawing No. | --        | 877*327*590<br>(34.53*12.87<br>*23.23) | 905*360*590<br>(35.63*14.17<br>*23.23) | 905*360*590<br>(35.63*14.17<br>*23.23) | 985*388*720<br>(38.78*15.28<br>*28.35) | 1075*485*860<br>(42.32*19.09<br>*33.86) | 1075*485*860<br>(42.32*19.09<br>*33.86) |
| Carton Material    | --        | Double Corrugated Cardboard            |                                        |                                        |                                        |                                         |                                         |
| Material Thickness | in (mm)   | 0.197 (5)                              | 0.197 (5)                              | 0.197 (5)                              | 0.197 (5)                              | 0.276 (7)                               | 0.276 (7)                               |


**Fig. 3 — Size 06K**



**Fig. 4 — Sizes 09K - 12K**






Fig. 5 — Size 18K




**Fig. 6 — Sizes 24K and 33K**

## CLEARANCES



**Fig. 7 — Clearances**

**NOTE:** The outdoor unit must be mounted at least 2in (50mm) above the maximum anticipated snow depth.



**Fig. 8 — Clearances for multiple units**

## INSTALLATION



### WARNING

#### Prior to Installation

Before installing the indoor unit, ensure the compatibility with the outdoor unit using the product data as a reference. It is also necessary to confirm the proper application of the equipment and to perform a heat load calculation for proper sizing.

- A location which is convenient to installation and not exposed to strong winds.
- A location which can bear the weight of the outdoor unit and where the outdoor unit can be mounted in a level position.
- A location which provides appropriate clearances (see Fig. 7).
- Allow sufficient space for airflow and service of the unit. See Fig. 7 for the required minimum distances between the unit or walls.

**NOTE: DO NOT install the indoor or outdoor units in a location with special environmental conditions. For those applications, contact your Ductless representative.**



### WARNING

#### PRODUCT INSTALLATION

Installation must be performed by an authorized dealer or specialist. A defective installation can cause water leakage, electrical shock, or fire.

The installation must be performed according to the installation instructions. Improper installation can cause water leakage, electrical shock, or fire. (In North America, installation must be performed in accordance with the requirements of NEC or CEC by authorized personnel only.)

Contact an authorized service technician for repair or maintenance of this unit. This appliance must be installed in accordance with local codes.

Only use the included accessories, parts, and specified parts for installation. Using non-standard parts can cause water leakage, electrical shock, fire, or unit failure.

To prevent exposure to wind, install the outdoor unit with its air inlet side facing the wall

Install drainage piping according to the instructions in this manual. Improper drainage may cause water damage to your home and property.

**DO NOT** install the unit in a location that may be exposed to combustible gas leaks. If combustible gas accumulates around the unit, it may cause a fire.

**DO NOT** turn on the power until all work has been completed.

When moving or relocating the system, consult experienced service technicians for the disconnection and re-installation of the unit.

**NOTE: Basepan built-in with multiple holes for proper draining during defrost. For applications where it is required to seal these holes, and re-direct the condensate drain, rubber plugs are available through RCD.**

**Table 7 — Base Pan Rubber Plugs**

| OUTDOOR UNIT MODEL<br>NUMBER PER UNIT | BASE PAN RUBBER PLUGS<br>RCD PART NUMBER | QTY. |
|---------------------------------------|------------------------------------------|------|
| 37MAHAQ06AA3                          | 12600801A00077                           | 30   |
| 37MAHAQ09AA3<br>37MAHAQ12AA3          | 12600801A00077                           | 23   |
| 37MAHAQ18AA3                          | 12600801A00077                           | 30   |
| 37MAHAQ24AA3<br>37MAHAQ33AA3          | 12600801A00117                           | 5    |

**IMPORTANT: Both refrigerant lines must be insulated separately. Use refrigeration grade tubing ONLY. No other type of tubing may be used. Use of other types of tubing will void the manufacturer's warranty.**

- The minimum refrigerant line length between the indoor and outdoor unit is 10 ft. (3m).
- When paired with Ductless indoor units, size the line sets based on the connection size of the indoor unit unless specified.
- When paired with conventional or multi-family fan coils, size the line sets based on the liquid and gas connection size of the outdoor unit; a field supplied reducer may be required.
- All outdoor units have an electronic expansion valve to manage the refrigerant flow of the fan coil connected.
- Do not open the service valves or remove the protective caps from the tubing ends until all connections are made.
- Bend the tubing with bending tools to avoid kinks and flat spots.
- Keep the tubing free of dirt, sand, moisture, and other contaminants to avoid damaging the refrigerant system.
- Avoid sags in the suction line to prevent the formation of oil traps.
- Insulate each tube with a minimum 3/8-in. (10 mm) wall thermal pipe insulation. Inserting the tubing into the insulation before making the connections saves time and improves installation quality.

R-454B



Refrigerant  
Safety Group  
**A2L**

R-454B

WARNING - Risk of Fire due to Flammable Refrigerant  
Used. Follow Handling Instructions Carefully in  
Compliance with National Regulations



349807-101 REV.-



## WARNING

All field piping must be completed by a licensed technician and must comply with the local and national regulations. When the system is installed in a small room, measures must be taken to prevent the refrigerant concentration in the room from exceeding the safety limit in the event of refrigerant leakage. If the refrigerant leaks and its concentration exceeds its proper limit, hazards due to lack of oxygen may result.

When installing the refrigeration system, ensure that air, dust, moisture or foreign substances do not enter the refrigerant circuit. Contamination in the system may cause poor operating capacity, high pressure in the refrigeration cycle, explosion or injury. Ventilate the area immediately if there is refrigerant leakage during the installation.

Leaked refrigerant gas is hazardous. Ensure there is no refrigerant leakage after completing the installation work.



## CAUTION

**DO NOT** install the connecting pipe until both the indoor and outdoor units have been installed.

Insulate both the gas and liquid piping to prevent condensation.



# REFRIGERANT PIPING

**Table 8 — Refrigerant Piping Table**


| MODEL                                                               |             | 37MAHAQ06AA3   | 37MAHAQ09AA3   | 37MAHAQ12AA3   | 37MAHAQ18AA3   | 37MAHAQ24AA3   | 37MAHAQ33AA3   |
|---------------------------------------------------------------------|-------------|----------------|----------------|----------------|----------------|----------------|----------------|
| Refrigerant Type                                                    | Type        | R454B          | R454B          | R454B          | R454B          | R454B          | R454B          |
| Charge Amount                                                       | lb. (kg)    | 2.03 (0.92)    | 2.2 (1.00)     | 2.2 (1.00)     | 3.46 (1.57)    | 3.97 (1.80)    | 5.45 (2.47)    |
| Additional refrigerant charge                                       | Oz/ft (g/m) | 0.16 (15)      | 0.16 (15)      | 0.16 (15)      | 0.16 (15)      | 0.32 (30)      | 0.32 (30)      |
| Liquid Pipe (size - connection type)                                | In (mm)     | 1/4in (6.35mm) | 1/4in (6.35mm) | 1/4in (6.35mm) | 1/4in (6.35mm) | 3/8in (9.52mm) | 3/8in (9.52mm) |
| Suction Pipe (size - connection type)                               | In (mm)     | 3/8in (9.52mm) | 3/8in (9.52mm) | 3/8in (9.52mm) | 1/2in (12.7mm) | 5/8in (15.9)   | 3/4in (19mm)   |
| Min. Piping Length                                                  | ft. (m)     | 9.8 (3)        | 9.8 (3)        | 9.8 (3)        | 9.8 (3)        | 9.8 (3)        | 9.8 (3)        |
| Standard Piping Length                                              | ft. (m)     | 24.6 (7.5)     | 24.6 (7.5)     | 24.6 (7.5)     | 24.6 (7.5)     | 24.6 (7.5)     | 24.6 (7.5)     |
| Max. Piping Length with no additional refrigerant charge per System | ft. (m)     | 24.6 (7.5)     | 24.6 (7.5)     | 24.6 (7.5)     | 24.6 (7.5)     | 24.6 (7.5)     | 24.6 (7.5)     |
| Total Maximum Piping Length per system                              | ft. (m)     | 82.02 (25)     | 82.02 (25)     | 82.02 (25)     | 98.42 (30)     | 164.04 (50)    | 164.04 (50)    |
| Max. outdoor-indoor height difference (OU higher than IU)           | ft. (m)     | 49.21 (15)     | 49.21 (15)     | 49.21 (15)     | 65.62 (20)     | 82.02 (25)     | 82.02 (25)     |
| Max. outdoor-indoor height difference (IU higher than OU)           | ft. (m)     | 49.21 (15)     | 49.21 (15)     | 49.21 (15)     | 65.62 (20)     | 82.02 (25)     | 82.02 (25)     |

Use the following steps to connect the refrigerant piping:

1. Run the interconnecting piping from the outdoor unit to the indoor unit.
2. Connect the refrigerant piping and drain line outside the indoor unit. Complete the pipe insulation at the flare connection then fasten the piping and wiring to the wall as required. Completely seal the hole in the wall.
3. Cut tubing to the correct length.

When preparing refrigerant pipes, take extra care to cut and flare them properly. This ensures efficient operation and minimizes the need for future maintenance.

- a. Measure the distance between the indoor and outdoor units.
- b. Using a pipe cutter, cut the pipe a little longer than the measured distance.
- c. Make sure the pipe is cut at a perfect 90° angle.


**Fig. 9 — Pipe Cutting**


## CAUTION

### DO NOT DEFORM PIPE WHILE CUTTING


Be extra careful not to damage, dent, or deform the pipe while cutting. This will drastically reduce the heating efficiency of the unit.

#### 4. Remove Burrs

Burrs can affect the air-tight seal of the refrigerant piping connection. Therefore, they must be completely removed.

To remove:


- a. Hold the pipe at a downward angle to prevent burrs from falling into the pipe.
- b. Using a reamer or deburring tool, remove all burrs from the cut section of the pipe.


**Fig. 10 — Deburring Tool**


#### 5. Flare Pipe Ends

Proper flaring is essential to achieving an airtight seal.

- a. After removing the burrs from the cut pipe, seal the ends with PVC tape to prevent foreign materials from entering the pipe.
- b. Sheath the pipe with insulating material.
- c. Place factory flare nut on pipe facing the proper direction. Make sure they are facing the right direction. Once the ends are flared, it is impossible to put them on or change their direction.


**Fig. 11 — Copper pipe and flare nut**

- d. Remove the PVC tape from ends of pipe when ready to perform the flaring work.
- e. Clamp the flare block on the end of the pipe. The end of the pipe must extend beyond the flare form.


**Fig. 12 — Flare Block**



- f. Place the flaring tool onto the form.
- g. Turn the handle of the flaring tool clockwise until the pipe is fully flared. Flare the pipe in accordance with the dimensions in Table 9.




Fig. 13 — Flare Shape

Table 9 — Flare Nut Spacing

| OUTER DIAMETER<br>IN (MM) | A" IN (MM)       |                 |
|---------------------------|------------------|-----------------|
|                           | MIN.             | MAX.            |
| Ø 1/4in (Ø 6.35mm)        | 0.0275in (0.7mm) | 0.05in (1.3mm)  |
| Ø 3/8in (Ø 9.52mm)        | 0.04in (1.0mm)   | 0.063in (1.6mm) |
| Ø 1/2in (Ø 12.7mm)        | 0.04in (1.0mm)   | 0.07in (1.8mm)  |
| Ø 5/8in (Ø 16mm)          | 0.078in (2.0mm)  | 0.086in (2.2mm) |
| Ø 3/4in (Ø 19mm)          | 0.078in (2.0mm)  | 0.094in (2.4mm) |

- h. Remove the flaring tool and flare block, then inspect the end of the pipe for cracks and even flaring.
6. Connect the Pipes  
Connect the copper pipes to the indoor unit first, then connect the pipes to the outdoor unit. Connect the low-pressure pipe first, then connect the high pressure pipe.
  - a. Align the center of the two pipes that you will connect.




Fig. 14 — Align the center of the two pipes

- b. Tighten the flare nut as much as possible by hand.
- c. Using a wrench, grip the nut on the unit tubing.
- d. While firmly gripping the nut, use a torque wrench to tighten the flare nut according to the torque values listed in Table 10.

Table 10 — Tightening Torque

| BRASS FLARE<br>SIZES | RECOMMENDED<br>SEATING TORQUE<br>FOR BRASS FLARE<br>NUTS |        | FLARE DIMENSIONS<br>(A) (INCH/MM) |           |
|----------------------|----------------------------------------------------------|--------|-----------------------------------|-----------|
|                      | Ft-Lbs                                                   | N-M    | Min                               | Max       |
| 1in (mm)             |                                                          |        |                                   |           |
| Ø 1/4 (6.35)         | 13.3-14.7                                                | 18-20  | 0.33/8.4                          | 0.34/8.7  |
| Ø 3/8 (9.52)         | 23.6-28.8                                                | 32-39  | 0.52/13.2                         | 0.53/13.5 |
| Ø 1/2 (12.7)         | 36.1-42.8                                                | 49-59  | 0.64/16.2                         | 0.65/16.5 |
| Ø 5/8 (16)           | 42-52.4                                                  | 57-71  | 0.76/19.2                         | 0.78/19.7 |
| Ø 3/4 (19)           | 49.4-74.5                                                | 67-101 | 0.91/23.2                         | 0.93/23.7 |
| Ø 7/8 (22)           | 62.7-81.1                                                | 85-110 | 1.04/26.4                         | 1.06/26.9 |

**NOTE: Use both a backup wrench and a torque wrench when connecting or disconnecting pipes to or from the unit.**




Fig. 15 — Torque wrench with backup wrench

**CAUTION**

Wrap insulation around the piping. Direct contact with the bare piping may result in burns or frostbite. Ensure the pipe is properly connected. Over tightening may damage the bell mouth and under tightening may lead to leakage.

All tubing bends should be performed with a properly sized tubing bender to prevent kinking or damaging the tubing.

- e. After connecting the copper pipes to the indoor unit, wrap the power cable, signal cable and the piping together with binding tape.

**NOTE: While bundling these items together, DO NOT intertwine or cross the signal cable with any other wiring.**

- f. Thread this lineset through the wall and connect it to the outdoor unit.
- g. Insulate all piping, including the outdoor unit valves.

**NOTE: DO NOT open the service valves until pressure test is complete.**

## 7. Pressure Test Piping

**CAUTION**

Only use Dry Nitrogen to pressure test refrigerant systems. Use of other gases can result in injury, property damage or death.

**NOTE: Use refrigeration gauges that are pressure rated for R454b refrigerant.**

- a. Attach low side gauge hose to the 5/16" Schrader valve on the outdoor unit service valve.
- b. Attach the charging hose to the regulator on the dry nitrogen tank.
- c. Preset the nitrogen regulator to 550 psi.
- d. Slowly pressurize the line set until the low side gauge reads 500 psi. Do not exceed 550 psi.
- e. Close all the valves on the nitrogen tank and gauges.
- f. Allow the pressure test to stand for a minimum of 30 minutes.
- g. If the pressure holds, release the nitrogen and proceed. Review "EVACUATE COIL AND TUBING SYSTEM" on page 18.
- h. If the pressure goes down in the 30 minute delay, leak check the tubing and flare fittings to identify the source of the leak. Return to Step C, above.

## EVACUATE COIL AND TUBING SYSTEM



### CAUTION

#### UNIT DAMAGE HAZARD


Failure to follow this caution may result in equipment damage or improper operation. Never use the system compressor as a vacuum pump.

Refrigerant tubes and the indoor coil should be evacuated using the recommended 500 microns deep vacuum method. The alternate triple evacuation method may be used if the procedure outlined below is followed.


**NOTE: Always break a vacuum with dry nitrogen.**

#### Using Vacuum Pump

1. Completely tighten flare nuts A, B, C, D. Connect the manifold gage charge hose to a charge port of the low side service valve (see Fig. 16).
2. Connect the charge hose to vacuum pump.
3. Fully open the low side of manifold gage (see Fig. 17).
4. Start the vacuum pump.
5. Evacuate using either the deep vacuum or triple evacuation method.
6. After evacuation is complete, fully close the low side of manifold gage and stop the vacuum pump operation.
7. The factory charge contained in the outdoor unit is good for up to 25 ft. (8 m) of line length. For refrigerant lines longer than 25 ft. (8 m), add refrigerant, up to the allowable length.
8. Disconnect the charge hose from the charge connection of the low side service valve.
9. Fully open service valves B and A.
10. Securely tighten the service valve caps.



**Fig. 16 — Service Valve**




**Fig. 17 — Manifold**

#### Evacuation

Evacuation of the system removes air or nitrogen (non-condensables) as well as moisture. A proper vacuum assures a tight, dry system before charging with refrigerant. The two methods used to evacuate a system are the deep vacuum method and the triple vacuum method.

#### Deep Vacuum Method

The deep vacuum method requires a vacuum pump capable of pulling a vacuum of 500 microns and a vacuum gauge capable of accurately measuring this vacuum depth. The deep vacuum method is the most positive way of assuring a system is free of air and moisture (see Figure 18).




**Fig. 18 — Deep Vacuum Graph**

#### Triple Evacuation Method

The triple evacuation method should be used when the vacuum pump is not capable of pumping down to 500 microns and system does not contain any liquid water. Refer to Fig. 19 and proceed as follows:

1. Attach refrigeration gauges and evacuate system down to 28 in. of mercury and allow pump to continue operating for an additional 15 minutes.
2. Close service valves and shut off vacuum pump.
3. Connect a nitrogen cylinder and regulator to system and flow nitrogen until system pressure is 2 psig.
4. Close service valve and allow system to stand for 1 hour. During this time, dry nitrogen will be able to diffuse throughout the system absorbing moisture.
5. Repeat this procedure as indicated in Fig. 19. System will then be free of any contaminants and water vapor.



**Fig. 19 — Triple Evacuation Method**

#### Final Tubing Check

**IMPORTANT:** Check to be certain factory tubing on both the indoor and outdoor unit has not shifted during shipment. Ensure tubes are not rubbing against each other or any sheet metal. Pay close attention to the feeder tubes, making sure wire ties on feeder tubes are secure and tight.

## WIRING

All wires must be sized per NEC (National Electrical Code) or CEC (Canadian Electrical Code) and local codes. Use Electrical Data table MCA (minimum circuit amps) and MOCP (maximum over current protection) to correctly size the wires and the disconnect fuse or breakers respectively.

**Power and Communication Wiring:** The main power is supplied to the outdoor unit. The field supplied 14/3 power/communication wiring, from the outdoor unit to the indoor unit, consists of four (4) wires and provides the power for the indoor unit. Two wires are high voltage AC power, one is communication wiring and the other is a ground wire.

**To minimize communication interference:** If installed in a high Electromagnetic field (EMF) area and communication issues arise, a 14/2 stranded shielded wire can be used to replace 2 (L2/N) and 3 (S) between the outdoor and indoor units - landing the shield onto the ground in the outdoor unit only.

Table 11 — Wiring Sizes

| CABLE            | CABLE SIZE | REMARKS                                                        |
|------------------|------------|----------------------------------------------------------------|
| Connection Cable | 14AWG      | 3 wire + Ground 1Φ 208/230 V<br>(Stranded wire is recommended) |



## WARNING

### EQUIPMENT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage or improper operation. Wires should be sized based on NEDC and local codes.



## CAUTION

### EQUIPMENT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage or improper operation. Be sure to comply with local codes while running wire from the indoor unit to the outdoor unit. Every wire must be connected firmly. Loose wiring may cause the terminal to overheat or result in unit malfunction. A fire hazard may also exist. Ensure all wiring is tightly connected.

No wire should touch the refrigerant tubing, compressor or any moving parts. Disconnecting means must be provided and shall be located within sight and readily accessible from the air conditioner. Connecting cable with conduit shall be routed through the hole in the conduit panel.

## Electrical and Gas Leaks



## WARNING

### BEFORE TEST RUN

Only perform test run after you have completed the following steps:

**Electrical Safety Checks** – Confirm that the unit's electrical system is safe and operating properly

**Gas Leak Checks** – Check all flare nut connections and confirm that the system is not leaking

Confirm that gas and liquid (high and low pressure) valves are fully open

## ELECTRICAL DATA

Table 12 — Electrical Data

| OUTDOOR UNIT                   |     | 06K          | 09K        | 12K        | 18K        | 24K        | 33K        |
|--------------------------------|-----|--------------|------------|------------|------------|------------|------------|
|                                |     | (208/230V)   | (208/230V) | (208/230V) | (208/230V) | (208/230V) | (208/230V) |
| MINIMUM CIRCUIT AMPACITY (MCA) | A   | 12           | 15         | 15         | 19         | 24.9       | 34         |
| MOP                            | A   | 15           | 15         | 15         | 20         | 25         | 35         |
| VOLTAGE-PHASE-FREQUENCY        |     | 208/230-1-60 |            |            |            |            |            |
| MAX – MIN VOLTAGE RANGE        |     | 253-187      |            |            |            |            |            |
| COOLING                        |     |              |            |            |            |            |            |
| RUNNING CURRENT                | (A) | 3.1          | 4.1        | 4          | 6.4        | 8.2        | 12.7       |
| POWER CONSUMPTION              | (W) | 333          | 580        | 890        | 1440       | 1846       | 2750       |
| HEATING                        |     |              |            |            |            |            |            |
| RUNNING CURRENT RANGE          | (A) | 4            | 4.1        | 4.1        | 7.2        | 11.1       | 13.7       |
| POWER CONSUMPTION              | (W) | 489          | 935        | 935        | 1618       | 2485       | 3131       |

\*Permissible limits of the voltage range at which the unit will operate satisfactorily.

### LEGEND

**FLA** - Full Load Amps

**MCA** - Minimum Circuit Amps


**MOP** - Maximum Overcurrent Protection

## INSTALL THE OUTDOOR UNIT

### Step 1 - Select the Installation Location

**NOTE:** Before installing the outdoor unit, select an appropriate location. The following details are standards designed to help select an appropriate location for the unit.

Proper installation locations meet the following standards:



- ☒ Meets all spatial requirements shown in Installation Space Requirements above.



- ☒ Good air circulation and ventilation.




- ☒ Firm and solid—the location can support the unit and will not vibrate.



- ☒ Noise from the unit will not disturb other people.



- ☒ Protected from prolonged periods of direct sunlight or rain.



- ☒ Where snowfall is anticipated, take appropriate measures to prevent ice buildup and coil damage.

**NOTE:** Install the unit in accordance with the local codes and regulations.

### ! CAUTION:

#### SPECIAL CONSIDERATIONS FOR EXTREME WEATHER

If the unit is exposed to heavy wind:


Install unit so the air outlet fan is at a 90° angle to the direction of the wind. If needed, build a barrier in front of the unit to protect it from extremely heavy winds. See Figures below.

If the unit is frequently exposed to heavy rain or snow:


Build a shelter above the unit to protect it from the rain or snow. Be careful not to obstruct air flow around the unit.

If the unit is frequently exposed to salty air (seaside):


Use outdoor unit that is specially designed to resist corrosion.



90° angle to the direction of the wind



Build a wind Baffle to protect the unit



Build a shelter to protect the unit


**DO NOT** install unit in the following locations:

- ⊘ Near an obstacle that will block air inlets and outlets
- ⊘ Near animals or plants that will be harmed by hot air discharge.
- ⊘ In a location that is exposed to large amounts of dust
- ⊘ Near a public street, crowded areas, or where noise from the unit will disturb others.
- ⊘ Near any source of combustible gas.
- ⊘ In a location exposed to a excessive amounts of salty air.

## Step 2 - Install the Drain Joint


**NOTE:** Before bolting the outdoor unit in place, you must install the drain joint at the bottom of the unit. For units with a base pan built-in (with multiple holes for proper draining during defrost), the drain joint is not needed to be installed.

1. Locate the outdoor unit's base pan hole.



**Fig. 20 — Base pan hole**

2. Fit the rubber seal on the end of the drain joint that connects to the outdoor unit.



**Fig. 21 — Fit the rubber seal**

3. Insert the drain joint into the hole in the base pan of the unit. The drain joint will “click” in place.
4. Connect a drain hose extension (not included) to the drain joint to redirect water from the unit during heating mode.

**NOTE:** In cold climates, ensure the drain hose is as vertical as possible to ensure swift water drainage. If water drains too slowly, it can freeze in the hose and flood the unit.


## Step 3 - Anchor the Outdoor Unit



### WARNING

When drilling into concrete, eye protection is recommended at **all** times.

- The outdoor unit can be anchored to the ground or to a wall-mounted bracket with bolt (M10). Prepare the installation base of the unit according to Figure 22.
- Table 13 lists outdoor unit sizes and the distance between their mounting feet. Prepare the installation base of the unit according to the dimensions listed in Table 13.



**Fig. 22 — Anchor Outdoor unit**

**Table 13 — Dimensions**

| OUTDOOR UNIT DIMENSIONS<br>W X H X D       | MOUNTING DIMENSIONS |                |
|--------------------------------------------|---------------------|----------------|
|                                            | DISTANCE A          | DISTANCE B     |
| 30.1inx 21.8inx 11.9in (765mmx555mmx303mm) | 17.8in (452mm)      | 11.3in (286mm) |
| 31.7inx 21.8inx 12.9in (805mmx554mmx330mm) | 20.1in (511mm)      | 12.5in (317mm) |
| 35.0inx 26.5inx 13.5in (890mmx673mmx342mm) | 26.1in (663mm)      | 13.9in (354mm) |
| 37.2inx 31.9inx 16.1in (946mmx810mmx410mm) | 26.5in (673mm)      | 15.9in (403mm) |

**If you install the unit on the ground or on a concrete mounting platform, perform the following steps.**

1. Mark the positions for four expansion bolts based on the dimensions chart.
2. Pre-drill holes for expansion bolts.
3. Place a nut on the end of each expansion bolt.
4. Hammer expansion bolts into the pre-drilled holes.
5. Remove the nuts from expansion bolts, and place the outdoor unit on bolts.
6. Put a washer on each expansion bolt, then replace the nuts.
7. Use a wrench to tighten each nut until snug.

**If you install the unit on a wall-mounted bracket, perform the following steps.**

1. Mark the position of bracket holes based on the dimensions chart.
2. Pre-drill the holes for the expansion bolts.
3. Place a washer and nut on the end of each expansion bolt.
4. Thread expansion bolts through holes in the mounting brackets, put mounting brackets in position, and hammer the expansion bolts into the wall.
5. Ensure the mounting brackets are level.
6. Carefully lift unit and place its mounting feet on brackets.
7. Bolt the unit firmly to the brackets.
8. If allowed, install the unit with rubber gaskets to reduce vibrations and noise.



### CAUTION

Ensure the wall is made of solid brick, concrete, or of similarly strong material. The wall must be able to support at least four times the weight of the unit.

Step 4 - Connect Signal and Power Cables

⚠

WARNING

All wiring work must be performed strictly in accordance with the wiring diagram located in the wire cover of the outdoor unit. Before performing any electrical or wiring work, turn off the main power to the system.

Connection Diagram




Fig. 23 — Connection Diagram


NOTES:

- 1. Do not use the thermostat wire for any connection between indoor and outdoor units.
- 2. All connections between the indoor and outdoor units must be made as shown in Figure 23. The connections are sensitive to polarity and will result in a fault code.




The outside unit's terminal block is protected by an electrical wiring cover on the side of the unit. A comprehensive wiring diagram is printed on the inside of the wiring cover.

1. Remove the wire cover from the unit by loosening the 3 screws.
2. Dismount the caps on the conduit panel.
3. Temporarily mount the conduit tubes (not included) on the conduit panel.
4. Properly connect both the power supply and low voltage lines to the corresponding terminals on the terminal block.
5. Ground the unit in accordance with local codes.
6. Be sure to size each wire allowing several inches longer than the required length for wiring.
7. Use lock nuts to secure the conduit tubes.



**Fig. 24 — Select the through-hole**

## Properly Connect the Wire Lines



**Fig. 25 — Properly Connect the Wire Lines**

1. The treatment about the end of the wire.
2. Connect the line to the corresponding terminals on the terminal block.



## START-UP

### Test Operation

Perform a test operation after completing a gas leak and electrical safety check. Review the indoor unit installation instructions and owner's manual for additional start up information.

### System Checks

1. Conceal the tubing where possible.
2. Ensure that the drain tube slopes downward along its entire length.
3. Ensure all tubing and connections are properly insulated.
4. Fasten the tubes to the outside wall, when possible.
5. Seal the hole through which the cables and tubing pass.

### Outdoor Unit

1. Are there unusual noises or vibrations during operation?  
**Explain the Following Items to the Customer (with the aid of the Owner's Manual):**
2. Explain care and maintenance.
3. Present the installation instructions to the customer.

## CARE AND MAINTENANCE

To help ensure high performance and minimize possible equipment failure, periodic maintenance must be performed on this equipment. Maintenance frequency may vary depending upon geographic areas.

## TROUBLESHOOTING

For ease of service, the systems are equipped with diagnostic code display LEDs on both the indoor and outdoor units. The outdoor diagnostic display has one red LED on the outdoor unit board and is limited to very few errors. The indoor diagnostic display is a combination of flashing LEDs on the display panel or the front of the unit.

There may be a few error codes displayed in the indoor unit that might relate to the outdoor unit's problems. If possible, always check the diagnostic codes displayed on the indoor unit first.

## ERROR CODES

**Table 14 — Error Codes**

| Display                                                                                                                                                                         | Malfunction and Protection Indication                                   |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------|
| <b>EC07</b>                                                                                                                                                                     | ODU Fan Speed Out of Control                                            |
| <b>EC51</b>                                                                                                                                                                     | ODU EEPROM Parameter Error                                              |
| <b>EC52</b>                                                                                                                                                                     | ODU Coil Temperature Sensor(T3) error                                   |
| <b>EC53</b>                                                                                                                                                                     | ODU Ambient Temperature Sensor (T4) Error                               |
| <b>EC54</b>                                                                                                                                                                     | COMP. Discharge Temperature Sensor (TP) Error                           |
| <b>EC56</b>                                                                                                                                                                     | IDU Coil Temperature Sensor (T2B) Error                                 |
| <b>ECC1</b>                                                                                                                                                                     | Other IDU Refrigerant Sensor Detects Leakage (Multi-zone)*              |
| <b>EH00</b>                                                                                                                                                                     | IDU EEPROM Malfunction                                                  |
| <b>EH03</b>                                                                                                                                                                     | IDU Fan Speed Out of Control                                            |
| <b>EH0A</b>                                                                                                                                                                     | IDU EEPROM Parameter Error                                              |
| <b>EH0E</b>                                                                                                                                                                     | Water Level Alarm Malfunction                                           |
| <b>EH12</b>                                                                                                                                                                     | Main Unit or Secondary Units Malfunction                                |
| <b>EH3A</b>                                                                                                                                                                     | External Fan DC bus voltage is too low protection                       |
| <b>EH3b</b>                                                                                                                                                                     | External Fan DC bus voltage is too high fault                           |
| <b>EH60</b>                                                                                                                                                                     | IDU Room Temperature (T1) Error                                         |
| <b>EH61</b>                                                                                                                                                                     | IDU Coil Temperature Sensor (T2) Error                                  |
| <b>EHba</b>                                                                                                                                                                     | Communication Error between the indoor unit and the external fan module |
| <b>EHC1</b>                                                                                                                                                                     | Refrigerant Sensor Detects Leakage                                      |
| <b>EHC2</b>                                                                                                                                                                     | Refrigerant Sensor is out of range and a leak is detected               |
| <b>EHC3</b>                                                                                                                                                                     | Refrigerant Sensor is out of range*                                     |
| <b>EL01</b>                                                                                                                                                                     | IDU and ODU Communication Error                                         |
| <b>EL0C</b>                                                                                                                                                                     | System lacks refrigerant                                                |
| <b>EL11</b>                                                                                                                                                                     | Communication Malfunction between the main and secondary units          |
| <b>FH07</b>                                                                                                                                                                     | IDU lift panel communication failure/IDU opening and closing failure    |
| <b>FHCC</b>                                                                                                                                                                     | Refrigerant Sensor Error*                                               |
| <b>PC00</b>                                                                                                                                                                     | ODU IPM Module Protection                                               |
| <b>PC01</b>                                                                                                                                                                     | ODU Voltage Protection                                                  |
| <b>PC02</b>                                                                                                                                                                     | Compressor To (or IPM Module Protection)                                |
| <b>PC03</b>                                                                                                                                                                     | Pressure Protection (Low or High Pressure)                              |
| <b>PC04</b>                                                                                                                                                                     | Inverter Compressor Drive Error                                         |
| <b>PC0L</b>                                                                                                                                                                     | Low Ambient Temperate Protection                                        |
| <b>NOTE:</b> The digital tube will display <b>FC</b> in the <b>FORCED COOLING</b> mode. <b>FC is NOT an error code.</b> *Applicable to the units with refrigerant sensors only. |                                                                         |

**Table 15 — Refrigerant Leak Detection Error Codes**

|             |                                                                                    |
|-------------|------------------------------------------------------------------------------------|
| <b>EHC1</b> | Refrigerant Sensor detects a leak                                                  |
| <b>EHC2</b> | Working condition of the refrigerant sensor is out of range and a leak is detected |

If you receive one of the codes in Table 15, call a technician as soon as possible. No need to panic, the unit goes into TURBO mode until the error code clears. There is a “beeping” noise coming from the indoor unit, which is normal in this case.

For additional diagnostic information, refer to the Service Manual.

## DUCTLESS START-UP CHECKLIST - Single Zone

### Installation Data

Site Address: \_\_\_\_\_

City: \_\_\_\_\_ State: \_\_\_\_\_ Zip Code: \_\_\_\_\_

Installing Contractor: \_\_\_\_\_ Contractor Contact #: ( ) \_\_\_\_\_ - \_\_\_\_\_

Job Name: \_\_\_\_\_ Start-up Date: \_\_\_\_\_

Distributor: \_\_\_\_\_

### System Details

| UNITS         | MODEL NO. | SERIAL NO. | CONTROLLER |
|---------------|-----------|------------|------------|
| OUTDOOR UNIT  |           |            |            |
| INDOOR UNIT A |           |            |            |

Are the outdoor unit and indoor unit compatible?

YES: \_\_\_\_\_ NO: \_\_\_\_\_

### Wiring Electrical

Wire Size and Type Used? AWG: \_\_\_\_\_ TYPE: \_\_\_\_\_

Are there any breaks, splices, wire nuts or butt connectors between the outdoor unit and the indoor unit?

YES: \_\_\_\_\_ NO: \_\_\_\_\_

Was the wiring from the outdoor unit port to the correct indoor unit verified?

YES: \_\_\_\_\_ NO: \_\_\_\_\_

REMARKS: \_\_\_\_\_

### Voltage Check

#### Wiring: Single Zone

|                                          |             |  |                                         |             |  |                                         |
|------------------------------------------|-------------|--|-----------------------------------------|-------------|--|-----------------------------------------|
| Outdoor Unit Disconnect                  | 1(L1):GND   |  | Outdoor Unit Terminal Block             | 1(L1):GND   |  | NOTES: _____<br>_____<br>_____<br>_____ |
|                                          | 2(L2):GND   |  |                                         | 2(L2):GND   |  |                                         |
|                                          | 1(L1):2(L2) |  |                                         | 1(L1):2(L2) |  |                                         |
| Indoor Unit Voltage Check @ Outdoor Unit | 1(L1):GND   |  | Indoor Unit Voltage Check @ Indoor Unit | 1(L1):GND   |  | NOTES: _____<br>_____<br>_____<br>_____ |
|                                          | 2(L2):GND   |  |                                         | 2(L2):GND   |  |                                         |
|                                          | 1(L1):2(L2) |  |                                         | 1(L1):2(L2) |  |                                         |
|                                          | 2(L2):3(S)  |  |                                         | 2(L2):3(S)  |  |                                         |

|                                          |             |  |                                         |             |  |                                         |
|------------------------------------------|-------------|--|-----------------------------------------|-------------|--|-----------------------------------------|
| Outdoor Unit Disconnect                  | 1(L1):GND   |  | Outdoor Unit Terminal Block             | 1(L1):GND   |  | NOTES: _____<br>_____<br>_____<br>_____ |
|                                          | 2(L2):GND   |  |                                         | 2(L2):GND   |  |                                         |
|                                          | 1(L1):2(L2) |  |                                         | 1(L1):2(L2) |  |                                         |
| Indoor Unit Voltage Check @ Outdoor Unit | 1(L1):GND   |  | Indoor Unit Voltage Check @ Indoor Unit | 1(L1):GND   |  | NOTES: _____<br>_____<br>_____<br>_____ |
|                                          | 2(L2):GND   |  |                                         | 2(L2):GND   |  |                                         |
|                                          | 1(L1):2(L2) |  |                                         | 1(L1):2(L2) |  |                                         |
|                                          | 2(L2):3(S)  |  |                                         | 2(L2):3(S)  |  |                                         |

## Ductless Start-Up Checklist (CONT)

### Piping

#### Leak Check:

System held 500 psig (max. 550psi) for a minimum of 30 minutes using dry nitrogen. YES: \_\_\_\_\_ NO: \_\_\_\_\_

#### Evacuation Method:

- Was the Triple Evacuation Method used as outlined in the installation manual? YES: \_\_\_\_\_ NO: \_\_\_\_\_
- Was the Deep Vacuum Method used as outlined in the installation manual? YES: \_\_\_\_\_ NO: \_\_\_\_\_
- Did the System Hold 500 microns for 1 hour? YES: \_\_\_\_\_ NO: \_\_\_\_\_
- Does the line set match the diameter of the evaporator connections? YES: \_\_\_\_\_ NO: \_\_\_\_\_
- For Conventional Fan Coils, does the line set match the outdoor unit size? YES: \_\_\_\_\_ NO: \_\_\_\_\_

#### Single Zone Piping:

Has the liquid pipe length been measured and the additional charge calculated? Size: \_\_\_\_\_ Length: \_\_\_\_\_ Charge: \_\_\_\_\_

#### NOTES:

**NOTE: Final Charge Amount must be recorded!**

| PORT | LIQUID SIZE |  | SUCTION SIZE |  | LENGTH | CHARGE | NOTES: _____ |
|------|-------------|--|--------------|--|--------|--------|--------------|
| A    |             |  |              |  |        |        | _____        |

### Performance Check

**For 1:1 Single Zone Systems:** Adjust the set-point to create an operational call for the desired testing operation. Allow the system to run for a minimum of 10 min. and record the following details:

(Operational data recorded on applicable heads with the wireless remote controller's **Point Check** function)

| UNIT | SET-POINT | MODE | T1 | T2 | T3 | T4 | Tb | Tp | Th | LA/Lr |
|------|-----------|------|----|----|----|----|----|----|----|-------|
| A    |           |      |    |    |    |    |    |    |    |       |

#### NOTE:

- T1 - Ambient Space Temperature Sensor
- T2 - IDU Coil Temperature Sensor
- T3 - Outdoor Coil Temperature Sensor
- T4 - Outdoor Ambient Temperature
- Tb - Suction Line Temperature @PMV
- Tp - Discharge Temperature Sensor
- Th - IPM Board Temperature
- LA/Lr - PMV Temperature

### Error Codes

Were there any error codes present at start-up?

YES: \_\_\_\_\_ NO: \_\_\_\_\_

|                          |  |        |
|--------------------------|--|--------|
| Indoor Unit Error Code:  |  | Notes: |
| Outdoor Unit Error Code: |  |        |
| Wall Controller:         |  |        |
| 24V Interface:           |  |        |

### Comments:

---



---



---