

Installation Instructions

IMPORTANT: Read these instructions completely before attempting to install the accessory Remote Magnetic Test/Reset Station.

SAFETY CONSIDERATIONS

Installation and servicing of air-conditioning equipment can be hazardous due to system pressure and electrical components. Only trained and qualified personnel should install, repair, or service this equipment.

Untrained personnel can perform basic maintenance functions such as cleaning and replacing air filters. All other operations must be performed by trained service personnel. When working on air conditioning equipment, observe precautions in the literature, on tags, and on labels attached to or shipped with the unit and other safety precautions that may apply.

Follow all safety codes. Wear safety glasses, protective clothing, and work gloves. Use quenching cloth for brazing operations. Have fire extinguisher available. Read these instructions thoroughly and follow all warnings or cautions included in literature and attached to the unit. Consult local building codes, the current editions of the National Electrical Code (NEC) NFPA 70. In Canada refer to the current editions of the Canadian electrical Code CSA C22.1.

Recognize safety information. This is the safety-alert symbol . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury. Understand these signal words: DANGER, WARNING, and CAUTION. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which **will** result in severe personal injury or death. WARNING signifies hazards which **could** result in personal injury or death. CAUTION is used to identify unsafe practices which **may** result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which **will** result in enhanced installation, reliability, or operation.

WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

Before installing or servicing system, always turn off main power to system and install lockout tag. There may be more than one disconnect switch. Turn off accessory heater power switch if applicable.

CAUTION

CUT HAZARD

Failure to follow this caution may result in personal injury.

Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate clothing.

WARNING

PERSONAL INJURY AND ENVIRONMENTAL HAZARD

Failure to relieve system pressure could result in personal injury and/or death.

1. Relieve pressure and recover all refrigerant before servicing existing equipment, and before final unit disposal. Use all service ports and open all flow-control devices, including solenoid valves.
2. Federal regulations require that you do not vent refrigerant into the atmosphere. Recover during system repair or final unit disposal.

GENERAL

The SD-TRM4 Remote Test/Reset Station is used with the SuperDuct™ four-wire duct smoke detector. Each remote test/reset station provides a green LED to indicate power, a red LED to indicate alarms, and a yellow LED to indicate trouble and detector dirty levels. The SD-TRM4 requires a magnetic to activate test and reset functions. (See Fig. 1.)




Fig. 1 - SD-TRM4

C14084

SPECIFICATIONS

Compatible Electrical Boxes	North American 1-gang box
	Standard 4-in square box, 1-1/2-in deep with 1-gang cover
LED Indicators	Alarm (red) Trouble (yellow) Power (green)
LED Type	Clear lens
Wire Size	14 to 22 AWG
Resistance Per Wire	10 Ω , max
Current Requirements	Included in controller specification
Compatible Detectors	SuperDuct™ Four-Wire Smoke Detectors
Operating Environment	
Temperature	32° – 131°F (0° – 55°C)
Humidity	93% RH, non-condensing
Storage Temperature	-20° to 60°C (-4° to 140°F)

REMOTE TEST/RESET STATION TESTS

Test/reset station alarm test using the SuperDuct™ Four-Wire Smoke Detector

The test/reset station alarm test checks a test/reset station's ability to initiate and indicate an alarm state.

⚠ CAUTION

ALARM SYSTEM ACTIVATION HAZARD

Failure to follow this caution may result in emergency alarm system activation and possible fines.

This test places the duct detector into the alarm state. Unless part of the test, disconnect all auxiliary equipment from the controller before performing the test. If the duct detector is connected to a fire alarm system, notify the proper authorities before performing the test.

To perform the alarm test using an SD-TRM4:

1. Hold the test magnet to the target area for seven seconds.
2. Verify that the test/reset station's Alarm LED turns on.
3. After performing an alarm test using an SD-TRM4, reset the sensor by holding the test magnet to the target area for two seconds.
4. Verify that the test/reset station's Alarm LED turns off.

INSTALLATION

Mount the remote test/reset station on a single gang box as shown in Fig. 2.




Fig. 2 - SD-TRM4 Installation Diagram

C14085

WIRING

Wire the remote test/reset station to the four-wire controller as shown in Fig. 3.




Fig. 3 - Wiring Diagram

C09366

