

# **Aspen COOLER PAD**

## **Installation Instructions**

1. Remove cooler pad frames from cooler.
2. Detach cooler pad wire retaining racks from pad frames and discard old pads.
3. After removing paper and plastic wrap, install new cooler pads into cooler pad frames. Fold excess pad material to create a neat fit.
4. Reinstall cooler pad wire retaining racks.
5. Reinstall cooler pad frames into cooler. Have a cool summer!  
*After your new pads get wet, the aspen fibers will expand and fill the pad frames.*

***Remember, regular cooler maintenance insures good cooler performance! Dial has a full line of quality parts to keep your cooler in top shape. To keep your cooler fresh, ask your retailer about Dial's FRESH AIRE™ and SCALE ELIMINATOR™.***

***DURABLE ASPEN FIBER  
EXPANDS WHEN WET***

---

***REPLACE PADS TWICE A  
YEAR FOR BEST COOLING***