

IMMERSION SERIES

Installation & Operation Instructions

PRECAUTIONS

•DO NOT RUN THE WIRING IN ANY CONDUIT WITH LINE VOLTAGE (24/120/230 VAC).

GENERAL INFORMATION

The Immersion sensor is a single point temperature sensor that is designed for use with electronic controllers in commercial heating and cooling building management systems. It is available with multiple thermistor or RTD options.

For optimal temperature readings, follow these tips:

- Apply thermal grease to the end of the probe before installation into thermowell (ACI Item #102595).
- The tip of the thermowell should be located in the middle of the pipe.
- The sensor thermowell should be installed against the flow of the water, where water temperature is well mixed (no stratification).
- Make sure the entire thermowell is immersed. If the thermowell is longer than the pipe diameter, the thermowell should be installed in an elbow or Tee.

THERMOWELL INSTALLATION

ACI's standard Immersion sensors are made to install into a $\frac{1}{2}$ " NPT female thread. Typically a Threadolet or Tee is installed into the pipe, but a hole can also be drilled and tapped.



FIGURE 1: ENCLOSURE DIMENSIONS

PLASTIC BOX (-PB)



GALVANIZED ENCLOSURE (-GD)





BELL BOX (-BB)





NEMA -4X (-4X)





THERMOWELL INSTALLATION

The pipe/system will need to be drained, unless a Hot Tap is being used. The recommend drill size is 23/32 in. (18 mm). Drill the hole, and tap the hole with $\frac{1}{2}$ "-14NPT.

Always use proper thread sealants on tapered pipe threads of the thermowell. Screw the thermowell into the Threadolet, Tee, or tapped hole, using a wrench to tighten it firmly. Refill the system and check for leaks.

Best practice is to apply thermal grease to the end of the probe, but not required. Insert and push the sensor probe into the thermowell. Turn the sensor probe assembly clockwise to tighten down completely. Refer to the **Wiring Instructions** (p. 2-3) to make necessary connections.

PROBE INSERTION

The immersion sensors "-I" include a welded thermowell but can be ordered without the thermowell ".INW" version. The ".INW" includes a standard ½" NPS process thread to be used with a machined thermowell or previously installed thermowell. Verify the existing thermowell insertion length of the pipe is suitable for your selected Immersion.

If the length of the probe is too large, the probe may be pressed into its enclosure - up to an inch of clearance.

Note: *Fabricated (welded) thermowells (-I) are not intended for moving water or high pressure service. Fluid velocity and wake frequency are primary factors in well failure. Machined thermowells (-IM) should be used in these types of applications. Fabricated thermowells are intended for tank, or low to no flow, applications.

FIGURE 3: ELBOW ASSEMBLY



FIGURE 4: TEE MOUNT ASSEMBLY



FIGURE 5: PROBE and IMMERSION



TABLE 1: PROBE LENGTH and INSERTION LENGTH

ACI PART #	IMMERSION LENGTH	PROBE LENGTH	
A/xx-I-2.5″-yy-zz	2.5″ (63.50 mm)	4.31" (109.47 mm) +/- 0.13" (3.30 mm)	
A/xx-I-4"-yy-zz	4.0" (101.60 mm)	5.81" (147.57 mm) +/- 0.13" (3.30 mm)	
A/xx-I-6″-yy-zz	6.25″ (158.75 mm)	7.81" (198.37 mm) +/- 0.13" (3.30 mm)	



MAXIMUM	MAXIMUM VELOCITY VS THERMOWELL INSERTION LENGHT MACHINED THERMOWELL									
Straight Shank Insertion Length "U"					Stepped Shank Insertion Length "U"					
Material:	Media Type:	1.0" (25.4 mm)	2.5" (63.5 mm)	8.0" (203.2 mm)		4.0" (101.6 mm)	6.0" (152.4 mm)	12.0" (304.8 mm)	18.0" (457.2 mm)	24" (609.6 mm)
304/316 SS	Air/Gas/Steam ¹	349 ft/s (106.3 m/s)	349 ft/s (106.3 m/s)	71.9 ft/s (21.9 m/s)		109 ft/s (33.2 m/s)	73.6 ft/s (22.4 m/s)	19.4 ft/s (5.9m/s)	8.8 ft/s (2.7m/s)	5.2 ft/s (1.6m/s)
304/316 SS	Water	360 ft/s (109.7 m/s)	360 ft/s (109.7 m/s)	71.9 ft/s (21.9 m/s)		82.2 ft/s (25.1 m/s)	26.9 ft/s (8.2 m/s)	11.3 ft/s (3.4m/s)	4.7 ft/s (1.43m/s)	2.5 ft/s (0.8m/s)

Note¹: Values are for Air/Gas/Steam and similar density media based upon Max pressure of 2900 PSI @ 1000°F (537.8°C) | Note²: Values are for Water (No Glycol or other Chemicals factored in) @ 68 °F (20°C) and max pressure of 5700 PSI. (Calculated to ASME PTC 19.3 TW-2016 Code B31.1) | Note³: 6-24" Machined Thermowells meet ASME PTC 19.3 TW-2016 Code B31.1.

MAXIMUM PRESSURE VS TEMPERATURE RATINGS TWO PART FABRICATED WELDED THERMOWELL							
Material:	70°F	200°F	400°F	600°F	800°F	1000°F	1200°F
	(21.1°C)	(93.3°C)	(204.4°C)	(315.6°C)	(426.7°C)	(537.8°C)	(648.9°C)
304/316 SS	982 PSI	820 PSI	675 PSI	604 PSI	550 PSI	510 PSI	290 PSI
	(67.7 Bar)	(56.6 Bar)	(46.5 Bar)	(41.6 Bar)	(37.9 Bar)	(35.1 Bar)	(20.0 Bar)

MAXIMUM FLUID VELOCITY RATINGS TWO-PART FABRICATED | WELDED THERMOWELL

Straight Shank Insertion Length "U"				
Material:	Media Type:	2.5" (63.5 mm)	4.0" (101.6 mm)	6.0" (152.4 mm)
304/316 SS	Air/Gas/Steam ²	169 ft/s (51.5 m/s)	61 ft/s (18.6 m/s)	20 ft/s (6.1 m/s)
304/316 SS	Water	88 ft/s (26.8 m/s)	20 ft/s (6.1 m/s)	10 ft/s (3.05 m/s)

Note²: Values are for Air/Gas/Steam and similar density media

WIRING INSTRUCTIONS

Open the cover of the enclosure. ACI recommends 16 to 26 AWG twisted pair wires or shielded cable for all sensors. Signal wiring must be run separate from low and high voltage wires (24/120/230VAC). All ACI thermistors and RTD temperature sensors are both non-polarity and non-position sensitive. All thermistor type units are supplied with (2) flying lead wires, and all RTD's are supplied with (2) or (3) flying lead wires – see **FIGURE 6** (pg. 4). The number of wires needed depends on the application.

Connect thermistor/RTD wire leads to controller analog input wires using wire nuts, terminal blocks, or crimp style connectors. All wiring must comply with all local and National Electric Codes. After wiring, attach the cover to the enclosure.

Note: When using a shielded cable, be sure to connect only (1) end of the shield to ground at the controller. Connecting both ends of the shield to ground may cause a ground loop. When removing the shield from the sensor end, make sure to properly trim the shield to prevent any chance of shorting.

Note: If the controller requires a (2) wire input for a RTD, connect the (2) common wires(same color) together. If the controller requires (3) wires, use (3) individual wires.



FIGURE 6: TEMPERATURE WIRING





TROUBLESHOOTING

PROBLEM	SOLUTION(S)
Sensor reading is incorrect	 Verify sensor wiring to controller is not damaged and has continuity. Verify sensor or wires are not shorted together. Verify controller is setup for correct sensor curve. Disconnect sensor wires, and take a resistance reading with a multimeter. Compare the resistance reading to the Temperature Vs Resistance Curves online: <u>http://www.workaci.com/content/thermistor-curves-0</u> Verify proper mounting location to confirm no external factors are affecting reading.
Sensor reads infinity/very high resistance	Sensor or wires are open
Sensor reads low resistance	Sensor or wires are shorted together
Erratic readings	Condensation on PCB board Bad wire connections

WARRANTY

The ACI Immersion Series temperature sensors is covered by ACI's Five (5) Year Limited Warranty, which is located in the front of ACI'S SENSORS & TRANSMITTERS CATALOG or can be found on ACI's website: www. workaci.com.

W.E.E.E. DIRECTIVE

At the end of their useful life the packaging and product should be disposed of via a suitable recycling centre. Do not dispose of with household waste. Do not burn.





PRODUCT SPECIFICATIONS

SENSOR NON-SPECIFIC					
Number Sensing Points:	One	One			
Storage Temperature Range:	-40 to 85 °C (-40 to 185 °F)				
Operating Humidity Range:	0 to 90% RH, non-condensing				
Probe Diameter Thermowell Bore Diameter:	0.250" (6.35mm) 0.260"				
Probe Material Thermowell Material:	304 Stainless Steel 304 Series Stainless Steel				
Wire Size	22 AWG (0.65 mm)				
Thermowell Instrument Process Thread Size:	½" NPS (National Pipe Straight) Female Thread Thread	½"NPT (National Pipe Tapered) Male			
Enclosure Specifications: (Temperature, Material, Flammability, NEMA/ IP Ratings)	"-GD" Enclosure: Galvanized Steel, -40 to 121 "-PB" Enclosure: ABS Plastic, UL94-HB, -30 to 9 "-BB" Enclosure: Aluminum, -40 to 121°C (-40 "-4X" Enclosure: Polystyrene Plastic, UL94-V2,	90 °C (-22 to 194 °F), Plenum Rated to 250 °F), Plenum Rated, NEMA 3R (IP 14)			
THERMISTOR					
Sensor Output @ 25°C (77°F): (Lead Wire Colors) *Does not include CL2P	A/1.8K: 1.8 KΩ nominal (Red/Yellow) A/3K: 3 KΩ nominal (White/Brown) A/AN (Type III): 10 KΩ nominal (White/White) A/AN-BC: 5.238 KΩ nominal (White/Yellow) A/CP (Type II): 10 KΩ nominal (White/Green) A/S0K: 50KΩ nominal (Brown/Yellow)	A/CSI: 10 KΩ nominal (Green/Yellow) A/10KS: 10 KΩ nominal (White/Blue) A/10K-E1: 10 KΩ nominal (Gray/Orange) A/20K: 20 KΩ nominal (Brown/Blue) A/100KS: 100 KΩ nominal (Black/Yellow)			
Accuracy 0-70°C (32-158°F):	A/1.8K Series: +/- 0.5 °C @ 25 °C (77 °F) and (+/-1.0 °C) (+/-1.8 °F)	A/10K-E1 Series: +/- 0.3 °C (+/- 0.54 °F) All Else: +/- 0.2 °C (+/- 0.36 °F)			
PLATINUM					
Sensor Output @ 0°C (32°F):	Α/100: 100 Ω nominal	Α/1K: 1 KΩ nominal			
A	+/- 0.06% Class A (Tolerance Formula: +/- °C = (0.15 °C + (0.002 * [t])) where [t] is the absolute value of Temperature above or below 0 °C in °C)				
Accuracy:	@ -40 °C (-40 °F): +/- 0.23°C (+/- 0.414 °F) @ 0 °C (32 °F): +/- 0.15°C (+/- 0.27 °F)	@ 200 °C 392 °F): +/- 0.55 °C (+/- 1.00 °F)			
BALCO					
Sensor Output @ 21.1 °C (70 °F): (Lead Wire Colors)	1 KΩ nominal (Orange/Yellow)				
Accuracy:	@ 21.1 °C (70 °F): +/- 1%				
NICKEL					
Sensor Output @ 21.1 °C (70 °F): (Lead Wire Colors)	1 KΩ nominal (Red/Red)				
Accuracy:	@ -40 °C (-40 °F): +/- 1.52 °C (+/- 2.73 °F) @ 0 °C (32 °F): +/- 0.4 °C (+/- 0.72 °F) @ 21.1 °C (70 °F): +/- 0.17 °C (+/- 0.34 °F)	@ 54.4 °C (130 °F): +/- 0.56 °C (+/- 1.00°F) @ 121 °C (250 °F): +/- 1.25 °C (2.25 °F)			

Œ







Version: 4.0 10000811



NO	TES			

NOTES	



N	DTES	
-		
-		-
_		-
-		-
-		-
_		_
		-

NOTES	



NOTES	

NOTES	
	-
	-
	_
	-
	_
	-
	-

