

# INSTRUCTIONS



Page 1 of 1

**\*99TA516039 A\***

Instruction Sheet Number: **99TA516039 A**

\*99TA516039 A\* (for RCD use only)

---

Description: CONNECTING ROD

Author: : G. Decarr

Date: June 3, 2005

Part Number: 06EA660026, 034, 085, 086

1. Remove and discard the bolts and washers holding the rod cap in place. (This hardware is only used to hold the rod and cap together during the bearing surface machining process.)
2. Assemble rod and cap to crankshaft utilizing the capscrews provided in this package. Torque capscrews to 10-12 ft. lbs.