INSTRUCTIONS



Page 1 of 1

99TA525026

Instruction Sheet Number: 99TA525026

99TA525026 (for RCD use only)

Description: MOTOR INSTALLATION INSTRUCTIONS

Author: Don Howerton

Date: May 17, 2007

Part Number: SEE LIST BELOW



ELECTRIC SHOCK HAZARD.

To avoid the possibility of electrical shock, open and tag all disconnects before installing this equipment.

This instruction sheet is to be used with the following motors:

HC37AE116	HC37XE116	HC37XE277	HC39GE238
HC39SB231	HC39SE651	HC39VA120	HC41SE115
HC41SE117	HC41SE121	HC41SE651	HC43AE115
HC43AE231	HC43SB116	HC43SZ116	HC45AE115
HC45AE116	HC45MF232	HC45SE116	HC45SE651
HC680004	HC680014	HC680018	HC680027
HC680062			

1. Install new motor to existing mounting bracket.

2. Five wire terminals are supplied in the bag with the instruction sheet and are to be mated to each motor wire lead.

3. Remove the original connector from the unit side of the wire harness leaving enough wire to connect to the new motor lead. Strip each wire 1/2" and crimp the supplied motor terminal to the lead covering the exposed copper wire.

4. Make sure the motor wire colors match the wire colors on the unit side.