

CLEANING GUIDE

CLEANING THE TANK



- 1** Ensure the battery door is closed securely.
- 2** Remove the tank from the base and set on a level surface away from the base to prevent exposing the base to harsh chemicals.
- 3** Empty the tank per chemical manufacturer recommendations and fill it about one-third full with clean water. A small amount of mild household detergent may be added. Replace the cap and gently slosh the water around the tank.



- 4** Install the tank on the base and spray the water until the tank has been emptied. Make sure to direct the spray toward an area that will not be damaged by residual chemicals in the tank.




- 5** Repeat the procedure with clean water until the tank is thoroughly clean. Wash outside of nozzles and dry with a cloth.



- 6** Wipe the outside of the tank with a clean, dry cloth.
- 7** Allow all pieces to completely dry before reinstalling parts and storing the unit. Always reinsert strainer before replacing tank cap.

CLEANING ELECTRICAL CONTACTS



Keep electrical contact posts between bottom of tank and base clean.

WARNING!

- Remove battery pack from tool before cleaning electrical contacts.
- Clean contacts with a dry, clean cloth only.

CLEANING THE FILTER



- 1** The pump filter is located at the bottom of the tank and requires a quarter turn counter-clockwise to remove.



- 2** Rinse the filter with clean water and mild household detergent.
- 3** Wipe off with a dry, clean cloth.



- 4** When dried, the filter should be reinserted into the pump with a quarter turn clockwise.