INSTALLATION MANUAL

This manual covers the following models:

- **E219**

Application Guide

The E219 is an optional accessory to WW160W (Wireless Wire.) When WW160W is installed outdoors, it must be weather protected. The E219 is a weather resistant junction box that can be used to weather protect WW160W.

Features:

- **Non-metallic junction box**
- **UL Listed with a NEMA 6P rating per Section 314, exception of the National Electrical Code**
- **Manufactured from PVC or PPO thermoplastic molding compound and featuring foam-in-place gasket lids attached with stainless steel screws.**

Dimensions (inches):

Width = 6″

Height = 6″

Depth = 4″

Includes:

- **4 Stainless steel screws for lid**
- **Rubber grommets for 3, 5, or 8 wire holes**

Steps to mounting WW160W in E219 Junction Box:

- **Mount the base plate of WW160W output module to the bottom of junction box.**
- **Drill hole big enough for thermostat wire or rubber grommet (rubber grommet may provide greater weather resistant seal)**
- **Feed thermostat wire through hole and connect to appropriate terminals (see WW160W instruction manual for wiring instructions)**
- **Plug WW160W into subbase**
- **Screw lid tightly onto E219**
- **Mount or place E219 where appropriate**

Optional rubber grommets

3 wire



5 wire



8 wire



® U.S. Registered Trademark. Patents pending.
Copyright © 2019 All rights reserved.